


MOBILE STAND

for the BalanceBox® 400 and 400H







WARNING MAXIMUM SLOPE

WARNING DO NOT PULL DOWN SLOPE

STAY ABOVE CART WHEN MOVING DOWN SLOPE



CAUTION

This cart is intended for use with a BalanceBox® height adjustable mount and flat screen or touchscreen TV or
Interactive whiteboard weighing not more than:

200 pounds (90 kg).

Use with other products may result in instability causing possible injury.



CAUTION

"This cart is Intended for use only with the maximum weights indicated. Use with products heavier than the maximum weights indicated may result in instability causing possible injury."




MOBILE STAND


for the BalanceBox® 400 and 400H Installation manual









Contents of the box




Assemble (● 10 mm)




Use the allan key and a rubber mallet to tap the wheels to lock them on the wheelpin





Mount the BalanceBox® bracket (2 options for mounting height)

Please refer to BalanceBox[®] Installation manual!



Lock BalanceBox® with safety screws at the bottom

