



**BalanceBox®650**  
For use with large touchscreens



Mount the wall frame covers

Mount Application cover




Mount the screen or touchpanel, use  
BalanceBox® accessories


Set the balance, use a drill-driver with a 13 mm socket on outer  
springs marked green. Drive counter-clockwise 5 seconds each,  
repeat until balanced

**BalanceBox®**  
HEIGHT ADJUSTABLE MOUNTS


**BalanceBox®650**  
For use with large touchscreens  
Installation manual




Partnr: 902811-02




Safety warnings, contents of the box, tools needed




Remove wall bracket E use 5 mm Allen key




Mount bottom wall bracket level to the wall  
Use min. 4 x 8mm. ( $\frac{5}{16}$ " ) screws (not included)




Remove application cover B



Remove wall-frame covers C and D



Lift BalanceBox onto the wall bracket, mark the top holes. Take BalanceBox down and drill holes



Fix at the bottom and level, then tighten.  
Use 5mm Allen key