




SMART™ whiteboard frame for the BalanceBox® 400H




Adjust the BalanceBox springs to balance




Take the board down from the hook




Mount 4 UNC bolts in the holes on the back of the board, do not tighten



Mount the board in the mounting slots as shown




Adjust the position of the board left/right to match the projector image, tighten the UNC bolts




Please refer to
BalanceBox® user
manual!


BalanceBox®
HEIGHT ADJUSTABLE MOUNTS

SMART™ whiteboard frame for the BalanceBox® 400H Installation manual







Contents of the box




Assemble part Y




Assemble part Z




Assemble first tube X




Assemble second tube X




Mount projector plate and projector (not included)




Install wiring (not included)




Fix wiring using tyraaps



Mount speakers and accessories (not included)



Mount SMARTboard™ for spring adjustment



Hang top of board on hook for spring adjustment