

Installation manual

Part nr. 902831-02


Mobile stand

For the BalanceBox®400 and 400H


Safety Instructions



Tools needed




The contents of the box




1

Assemble (● 10 mm)



2

Use the allen key and a rubber mallet to tap the wheels to lock them on the wheelpin




Mobile stand

For the BalanceBox®400 and 400H

3


Mount the BalanceBox® bracket
(2 options for mounting height)

Included with
BalanceBox®




4

Please refer to:
BalanceBox® Installation Manual




5

Lock BalanceBox®400 with safety screws at the bottom




6




Mobile stand


For the BalanceBox®400 and 400H



WARNING MAXIMUM SLOPE



WARNING DO NOT PULL DOWN SLOPE



STAY ABOVE CART WHEN MOVING DOWN SLOPE



CAUTION

This cart is intended for use with a BalanceBox® height adjustable mount and flat screen or touchscreen TV or Interactive whiteboard weighing not more than:

200 pounds (90 kg).

Use with other products may result in instability causing possible injury.



CAUTION

"This cart is Intended for use only with the maximum weights indicated. Use with products heavier than the maximum weights indicated may result in instability causing possible injury."